Chapter 9 Diversions

Contents

Page

Introduction 9-1
Requirements for use 9-1
Planning considerations 9-1
Data collection 9-6
Engineering surveys 9-6
Hydrologic investigations 9-6
Soils investigations 9-6
Design of diversions 9-6
General 9-6
Velocities 9-8
Channel cross section 9-8
Grades 9-10
Capacity 9-10
Stability 9-10
Channel lining 9-11
Steps in designing a diversion 9-11
Example parabolic diversion design 9-11
Example trapezoidal diversion design 9-11
Layout and construction 9-12
Layout 9-12
Adjustment and marking 9-12
Construction 9-12
Preparation of site 9-12
Allowance for settlement 9-12
Methods 9-13
Industrial tractor with blade 9-13
Motor patrol grader 9-13
Scrapers 9-13
Other equipment 9-13
Checking construction 9-13
Establishment of vegetation 9-13
Outlets 9-14
Maintenance 9-14
General 9-14
Care of vegetation 9-14
Removal of sediment 9-14
Repair of eroded areas, breaks, and rodent holes 9-15
Reseeding 9-15
Paving or riprap 9-15
Outlets 9-15
Design Procedure For Diversions 9-49

(EFM Notice IN48, June 1986)

Figures

Page

9-1 Typical diversions 9-3
9-2 Site survey information 9-5
9-3 Diversion at boundary of land uses 9-5
9-4 Diversion at base of upland slope 9-5
9-5 Ridge diversion 9-7
9-6 Channel diversion 9-7
9-7 Combination diversion 9-7
9-8 Typical diversion cross sections 9-9
9-9 Woody vegetation on back slope 9-9

Exhibits

9-1 Parabolic diversion design chart—D and B retardance 9-17
9-2 Parabolic diversion design chart—D and C retardance 9-31
9-3 Diversion design table—D retardance (V and trapezoidal section) 9-45
9-4 Diversion design table—C retardance (V and trapezoidal section) 9-47